



Sony Ericsson W810i Keypad Replacement

Remove the W810i keypad from the W810i cellular phone

Written By: Ben Micucci



INTRODUCTION

This guide will show the user how to remove the keypad



TOOLS:

- [Phillips #00 Screwdriver](#) (1)
 - [T6 Torx Screwdriver](#) (1)
 - [T7 Torx Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
-

Step 1 — Keypad



- Make sure phone is off, and press down firmly against the Cingular icon with your thumb
- Slide the panel down and remove latch

Step 2



- Lift and Pull battery out
- Remove the SIM card too if you have one

Step 3




- Remove the two outer screws using a T-7 head for a screwdriver

Step 4



- Remove the two smaller inner screws with the Mini-Phillips screwdriver head

Step 5



- Remove the Back (camera side) Faceplate with the blue hand-wedge

Step 6



- Flip phone over and pry off the Front (Keypad side) Faceplate with multiple blue hand-wedges
- Separate keypad from logic board by turning it upside down and allowing it to fall off

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 03:21:38 PM.